

ROBOTRAX

the power to innovate



Inside heights



Inside widths



kabelschlepp.de

Fon: +49 2762 4003-0

OnlineEngineer.de
KABELSCHLEPP
Cable Carrier Configurator

3D-LINE – ROBOTRAX

Cable carriers for 3D movements

- For three-dimensional movements
- Can be deployed on robots for swiveling and rotational movements:
The same system for robot feet and arms
- With channel system, it is a universal solution for rotary applications
- Also ideally suited for rotary tables
- Optimum system for long service life of the cables:
 - The minimum bend radius can be maintained
 - The cables are cleanly isolated in three separate chambers

Special plastic for long service life

Easy fastening on every chain link with quick-opening mounting bracket possible

Steel cable for transmission of extremely large tensile forces

Open design
– Fast cable laying by simple pressing in of the cables – no threading through is necessary
– Simple inspection of all the cables



Protective covers or heat shields made of different materials are available for different environmental conditions



ROBOTRAX accessories



Impact protection



Chucking device



LineFix saddle-type clamps for strain relief*



Bend radius determiner



Quick-opening bracket on a rotary plate



Quick-opening bracket on a helical spring

* for types R075, R085 and R100

ROBOTRAX – cable carrier for 3D movements

Design principle

Inside heights

10
—
31

Inside widths

27
—
64



Chain links

The basic structure of ROBOTRAX consists of plastic links.

These have ball and socket style snap-together connectors on both sides. The individual links can thus be snapped together to form a cable carrier.

Internal bend radius stoppers ensure that the minimum bend radius is maintained in all directions.

Radial link rotation movement is also possible (see table).



Steel wire and shim bolts

When the robot arms are moving quickly, high accelerations occur, exerting high pulling forces on the cable carrier.

To be able to transmit these pulling forces ROBOTRAX has a hole in the middle of every chain link, through which a steel wire is drawn. This steel wire adopts the role of force transmission. The steel wire has a shim bolt attached to each end. As a result ROBOTRAX can achieve accelerations up to 10 g and higher.

Long service life of the cables and hoses:

The forces are transmitted by the cable carrier and not by the cables and hoses.



Quick-opening mounting brackets

The fixing and further guidance of the ROBOTRAX (on the arms of the robot) is achieved by means of quick-opening mounting brackets, fastened with two screws.

The quick-opening mounting brackets fit any chain link.

The fastening points can therefore be individually matched to the movement sequence of the robot.



Quickly opened:

Simply unlock the lynch pin, pull it out and open the quick-opening mounting bracket.


ROBOTRAX – cable carrier for 3D movements

Dimensions

Dimensions of ROBOTRAX cable carrier

Type	R 040	R 056	R 075	R 085	R 100
For cable-Ø	2 – 8.5	2 – 11	3 – 18	3 – 20	3 – 27
Bend radius	80	115	145	175	195
Radial link rotation over 1 m length	± 450°	± 300°	± 215°	± 215°	± 215°
D _a	40	56	75	85	100
B _i	27	39	52	54	64
h _i	10	14	22	24	31
t	21.5	32	40	40	40

Dimensions in mm



Inside heights





Inside widths



Dimensions of ROBOTRAX quick-opening bracket

Type	R 040	R 056	R 075	R 085	R 100
h ₁	54	70	86	105	120
l ₁	15	22	28	30	32
b ₁	82	86	110	133	150
b ₂	50	63	82	96	112
b ₃	36	48	64	72	70
b ₄	18	24	32	36	35

Dimensions in mm



Screwing of the quick-opening bracket:

- R 040, R 056 with M4 hexagonal screws
- R 075 with M6 hexagonal screws
- R 085, R 100 with M8 hexagonal screws

Example of ordering

Cable carrier						
R 075	·	010	-	145	-	1000
Type		Design*		Bend radius KR in mm		Chain length L _k in mm (without connection)

* Design 010 (simple insertion of the cables)

Ordering accessories: please state separately.

kabelschlepp.de

Font: +49 2762 4003-0

OnlineEngineer.de
with KABELSCHLEPP
 Cable Carrier Configurator

ROBOTRAX – accessories

Inside heights

10
—
31

Inside widths

27
—
64



Impact protection

When a robot is moving, a striking of the ROBOTRAX against machine components often cannot be avoided.


An impact protective device made of elastomer plastic can easily be attached to each link using a cable tie.



Heat shield/Protective sleeve

Heat shield: The heat shield, made of aluminium-coated textile fiber, protects the cable carrier and the cables within from flying sparks. A heat shield is recommended where there are flying sparks.

Protective sleeve: The protective sleeve made of layered polyester offers protection against aggressive cutting and hydraulic oils as well as from fine dusts and paint sprays (not illustrated).



Chucking device

This can be used to set the steel wire to the desired tension quickly and easily, and can be readjusted at any time.



Strain relief

For securing the cables and hoses.

(A strain relief device cannot be used on the same end of the ROBOTRAX as a chucking device.)



Strain relief with LineFix saddle-type clamps LFR

(for types R075, R085 and R100)

For secure and gentle cable fixing.

Multilayer strain relief with double and triple clamps possible. Multiple systems can also be mounted one behind the other.

ROBOTRAX – accessories



Bend radius determiner


This is used to achieve larger bend radii than the standard bend radius, e.g. in order to maintain the minimum bend radius of the cables.



Quick-opening bracket mounted on a rotary plate

Yet one more degree of freedom on the fastening points.

The quick-opening mounting bracket can also rotate on a rotary plate, thus providing greater flexibility when the robot is performing complex movements.



Quick-opening bracket on a helical spring

If the bracket is mounted on a helical spring, it can give elastically in all directions, swivel, swing out in 3 dimensions and spring back into place again.



Inside heights



Inside widths



kabelschlepp.de

Font: +49 2762 4003-0

OnlineEngineer.de
KABELSCHLEPP
Cable Center Configurator


ROBOTRAX – cable carrier for 3D movements

Part numbers for ordering

Inside heights



Inside widths



Mounted chain links

Type	R 040	R 056	R 075	R 085	R 100
Bend radius	80	115	145	175	195
Number of links	47	31	25	25	25
Part no.	60301	60401	60501	60601	60701

Quick-opening bracket for ROBOTRAX

Type	R 040	R 056	R 075	R 085	R 100
Part no.	260410	260510	260110	260210	260310

Shim bolts – 2 pieces (one pair)

Type	R 040	R 056	R 075	R 085	R 100
Part no.	260420	260520	260220	260220	260320

Steel wire – Please specify total length or partial lengths

Type	R 040	R 056	R 075	R 085	R 100
Ø	1.8	2.5	3.0	3.0	4.0
Part no.	60583	60584	60580	60580	60581

Strain relief – 1 piece

Type	R 040	R 056	R 075	R 085	R 100
Part no.	60658	60657	60659	60659	60659

Locating bolt for LineFix strain relief LFR – 1 piece

Type	R 075	R 085	R 100
Part no.	60669	60669	60669

LineFix strain relief – see page 302.

Chucking device set – 1 chucking device and 1 shim bolt

Type	R 040	R 056	R 075	R 085	R 100
Part no.	260430	260530	260230	260230	260330


Impact protection

Type	R 075	R 085	R 100
Part no.	260120	260240	260340

Packing unit: 5 complete items
consisting of: 10 semi-circular shells and 5 cable ties

ROBOTRAX – cable carrier for 3D movements

Part numbers for ordering



Heat shield/Protective sleeve

Type	R 040	R 056	R 075	R 085	R 100
Heat shield	60801	60802	60803	60804	60805
Protective sleeve (not illustrated)	60806	60807	60808	60809	60810

Please specify total length or partial lengths.

Inside heights




Inside widths



kabelschlepp.de

Fon: +49 2762 4003-0


OnlineEngineer.de
with CONCEPT Cable Carrier Configurator



Bend radius determiner

Type	R 075	R 085	R 100
Part no. 60830	160	230	280
Part no. 60831	190	265	310
Part no. 60832	220	300	340
Part no. 60833	250	335	370
Part no. 60834	280	370	400
Part no. 60835	310	405	430
Part no. 60836	340	440	460
Part no. 60837	370	475	490
Part no. 60838	400	510	520
Part no. 60839	430	545	550


Dimensions in mm



Rotary plate for quick-opening bracket

Type	R 040	R 056	R 075	R 085	R 100
A	57	65	82	96	112
B	57	57	57	70	70
C	43	43	43	75	75
D	43	43	43	45	45
E	36	48	64	72	70
H	25	25	25	34	34
d ₁	M6	M6	M6	M6	M6
d ₂	M4	M4	M6	M8	M8
Part no.	260580	260590	260550	260560	260570

Appropriate screws are supplied with the rotary plate. Dimensions in mm



Helical spring for quick-opening bracket

Type	R 040	R 056	R 075	R 085	R 100
A	52	64	82	96	112
B	36	48	64	72	70
C	5	5	6.5	8.5	8.5
Length L = 110 mm Part no.	260600	260620	–	–	–
Length L = 150 mm Part no.	260610	260630	–	–	–
Length L = 165 mm Part no.	–	–	60816	60820	60824
Length L = 190 mm Part no.	–	260640	–	–	–
Length L = 230 mm Part no.	–	–	60817	60821	60825
Length L = 315 mm Part no.	–	–	60818	60822	60826
Length L = 465 mm Part no.	–	–	60819	60823	60827

Dimensions in mm